


Getting Started



Unpack your UV Jewelry Glazing Oven taking care to carefully remove the paper stuffed inside, this paper is keeping the bulbs in place. Gently but firmly push on the end of each of the bulbs to make sure they did not become loose during shipping.

To use the glazing oven pull out the bottom tray (tinted blue), for our purpose we will not be using this tray. Plug the glazing oven in and press down on the front of the black button (with the single “—” mark), check to see if all 4 of the lights are lit, if not turn it off, unplug and press in any bulb(s) that did not light, they should snap into place.

Your glazing oven is now ready for use. Put your items to be cured on a flat level surface, I recommend a piece of glass or plastic at least as big as the glazing oven or tape down a piece of wax paper to your work table. Add epoxy to your items. Then place the glazing oven over the items so they end up below the lights and press the front of the black button down to turn the oven on. (The red button and back of the black button are for timing but it only times 2 minutes so we don't use it for epoxy.

Leave the glazing oven on for 20 minutes. At the end of the 20 minutes turn the power switch off, then lift the glazing oven of the items and you are done.

That's it.

Care and feeding of your UV Glazing Oven

To clean the glazing oven, wipe with a paper towel. You can use a lightly damp cloth if needed but be sure to unplug the unit first.

Use the oven only on a dry flat surface indoors. When not in use, unplug the oven. Do not operate the oven with a burned out or missing bulb, doing so will damage the unit and may pose a fire hazard. Do not stare into the lights for extended periods of time.



If the oven seems to be malfunctioning in any way, immediately turn the oven off and unplug it until the problem is fixed.

To change a bulb, turn the oven off and unplug it. Grasp the bulb firmly and pull towards the front of the unit, you may use a cloth to get a better grip on the bulb if needed. Once removed simply push a new bulb into the socket and push in until it's seated all the way into the socket, it should snap into place. If the bulb burned out over time it is a good idea to replace all of the bulbs at once since the rest are near the end of their life.

Store the glazing oven unplugged and out of direct sunlight and away from hot items such as a radiator or heater.

Contact EpoxyJewelry.com for replacement bulbs or any questions you might have about the operation of your UV glazing oven.